

LUNDAMAN Classic

The easy-to-use loading scales that anyone can use



Settings buttons

User menu

Button for switching bucket or equipment

Remove residual weight

Button for zeroising and printing out total weight/
Confirmation button

Button to cancel recording of the last bucket
in the event of overload/
Switch loading scales on or off

Size 195 x 101 x 44 mm

Properties and advantages

- Only two buttons used in day-to-day work
- Large and clear display
- Weighs during driving
- Independent of r.p.m.
- Accurate weighing with duplicate sensors (less than 1% variation)
- 20 separate working memories
- Possible to set tare to zero if material gets stuck in the bucket
- Separate weighing of truck and trailer on the same bill of weight
- Remove residual weight in the bucket
- Facility to cancel recording of the last bucket
- Pause function
- Use the same instrument in several machines
- Switch between tonne and kg
- The keypad and display have adjustable background lighting
- All sensors and cables are IP 65 classified
- Memory for 10 different items of equipment etc
- Printout of old weighings

Accessories

- Assembly kit for additional machines (move instruments and printers between machines)
- Printer with 114 mm wide paper including complete bill of weight text for individual layout, with incrementing bill of weight number
- External OK button

